

Kit réparation solenoïd et solenoïds

Kir réparation solenoïd			Solenoïd complet		
DR487	AMC	1959-1968	SS300	Chrysler	1960-1965
	Buick	1957-1969		Dodge truck	1964-1969
	Cadillac	1957-1969		Dodge	1961-1969
	Chev/GMC truck	1964-1969		Plymouth	1961-1969
	Chevrolet	1957-1969			
	Ford	1969-1969	SS304	AMC	1961-1968
	Jeep	1966-1969		Buick	1957-1969
	Lincoln	1968-1969		Cadillac	1957-1969
	Mercury	1969-1969		Chev/GMC truck	1960-1969
	Oldsmobile	1957-1969		Chevrolet	1957-1969
	Pontiac	1956-1969		Jeep	1966-1969
				Oldsmobile	1957-1969
CR481	Chrysler	1962-1969		Pontiac	1956-1969
	Dodge truck	1964-1969		Studebaker	1965-1966
	Dodge	1962-1969			
	Plymouth	1962-1969	SS305	AMC	1957-1959
				Buick	1954-1956
CR482	Chrysler	1969-1969		Cadillac	1954-1956
	Dodge	1969-1969		Chev/GMC truck	1955-1956
	Plymouth	1969-1969		Chev/GMC truck	1960-1962
				Chevrolet	1955-1956
CR483	Chrysler	1962-1969		Oldsmobile	1954-1955
	Dodge	1969-1969		Pontiac	1955-1955
	Plymouth	1969-1969			
			SS306	Ford	1968-1969
				Lincoln	1969-1969
				Mercury	1968-1969
			AM434	AMC	1961-1962
			F490	Ford	1956-1969
				Mercury	1956-1969
			F496	AMC	1968-1969
				Ford truck	1952-1969
				Ford	1956-1969
				Lincoln	1956-1969
				Mercury	1956-1969
				Studebaker	1956-1964
			F1490	Ford truck	1950-1951
				Ford	1950-1950
				Lincoln	1950-1951
				Mercury	1950-1951
			F1495	Ford truck	1952-1955
				Ford	1951-1955
				Lincoln	1952-1955
				Mercury	1952-1955
			AL429	Jeep	1952-1967
			AL436	Jeep	1958-1968
				Plymouth	1961-1961